PowderProof® | mobile powder sampling





PowderProof® | mobile powder sampling















- Many uses
- Stainless steel AISI 316L (1.4404)
- ▶ Incl. motor, two rechargeable batteries, lance, spiral srew, bags, fast charger, clip for holding the bag and cleaning brush
- ▶ Additional augers available as accessory

Use

- 1. The lance is inserted into the sack/container with the spiral screw rotating.
- 2. The powder or granules are immediately transported through the lance and filled directly into a sample bag or bottle at the lance outlet.





PowderProof® for horizontal...

... and vertical use

PowderProof®			Auga autoclave 121°
Model	Lance	Insertion depth mm	Item no.
for powders up to 2 mm dia.	horizontal	300	5302-0302 N2
for powders up to 2 mm dia.	vertical	600	5302-0602 N2
for powders up to 2 mm dia.	vertical	900	5302-0902 N2
for powders up to 2 mm dia.	vertical	1200	5302-1202 N2
for granules from 2 up to 4 mm dia.	horizontal	300	5302-0301 N2
for granules from 2 up to 4 mm dia.	vertical	600	5302-0601 N2
for granules from 2 up to 4 mm dia.	vertical	900	5302-0901 N2
for granules from 2 up to 4 mm dia.	vertical	1200	5302-1201 N2

Accessories		
Description	Item no.	
Spiral screw PowderProof® for powders up to 2 mm dia., for 300 mm	5302-0312	N2
Spiral screw for PowderProof® for powders up to 2 mm dia., for 600 mm	5302-0612	N2
Spiral screw for PowderProof® for powders up to 2 mm dia., for 900 mm	5302-0912	N2
Spiral screw for PowderProof® for powders up to 2 mm dia., for 1200 mm	5302-1212	N2
Spiral screw for PowderProof® for granules 2–4 mm dia., 300 mm	5302-0311	N2
Spiral screw for PowderProof® for granules 2 - 4 mm dia., for 600 mm	5302-0611	N2
Spiral screw for PowderProof® for granules 2 - 4 mm dia., for 900 mm	5302-0911	N2
Spiral screw for PowderProof® for granules 2 - 4 mm dia., for 1200 mm	5302-1211	N2
Bag clip for PowderProof®	0006-6259	N4
Transport case LxWxH 123x25x11 cm (not for 1200 mm)	3600-2120	N4
Sampling bottle LDPE 500 ml	0318-0500	N3
Basket for sample bottles 500 ml, Ø 84 mm, incl. holding ring	5302-2050	N2
Basket for sample bottles 1000 ml, Ø 100 mm, incl. holding ring	5302-2100	N2
Packaging bags with closure, 170x120 mm, 400 ml, 100 pieces	2348-0005	N3