

XS

TEMP

DIGITAL THERMOMETER

74 *vio*

WARRANTY
3
YEARS

N° 4 PT 100 inputs
Resolution 0,01 °C
4", full-color, high-definition display
Datalogger (190.000 data) - 3 modes
Multiview screen
Multilingual (ITA - ENG - FR - DE - ESP)
Programmed data logger
Password for data protection and calibration
Probes ID
Reference Probe
Alarms



BRILLIANT MEASURE!

The new color graphic TFT display allows measurements to be read in any light conditions. Indoors or in the field, in the dark or in the sun, the reading will always be clear.

The light or dark theme allow you to customize the instrument to your liking.



XS
INSTRUMENTS



1..2...3...4 PT100 INPUTS!

Up to 4 simultaneous measurements with maximum accuracy.

Calibration of the 4 measurement chains is also completely autonomous, providing maximum flexibility.



Temp 74 is supplied with a handy suitcase for a resistant and capacious carriage.

NEW FEATURES

ID :

You can enter an identifier for each measurement channel.

Reference probe

it will be so easy to compare different measurements!

Password:

Protect memory, calibrations and settings.

Alarms:

enables a minimum and a maximum threshold. If the temperature trespasses you will be notified immediately.

#organization

#speed

#security

#quality

DATA LOGGER



Manual

Click and save!



Automatic

The logger saves data independently with a predetermined frequency. It is possible to enter a delay in departure.



Programmed

Set start date, end date and frequency of savings. You can go on vacation with peacefully!

ENDLESS MEMORY

More than 190,000 storable data make Temp 74 a true data logger. Even the longest analyses can be stored without difficulty.

DATALINK+

The free DataLink+ software, available at www.giorgiobor-mac.com, allows data to be organized and exported in .pdf and .xls formats.

By taking advantage of computer memory, data storage will become infinite, and all possible views on the instrument will become usable by the software.

SUPPORT

Magnetic and with strap laces, with probe holder. You will always have your hands free.



Download	Esporta in Excel	Apri da File
M+	Esporta in PDF	Seleziona la lingua
Svuota	Salva su File	
Tabella	Grafico	

#	Data	Ora	Valore	U.M.	Modo	Temp	U.M.	MTC/ATC
1	18/05/2023	10:49:58	21,54	°C	CH1	21,54	°C	ATC
1	18/05/2023	10:49:58	21,51	°C	CH2	21,51	°C	ATC
1	18/05/2023	10:49:58	21,15	°C	CH3	21,15	°C	ATC
1	18/05/2023	10:49:58	20,98	°C	CH4	20,98	°C	ATC
2	18/05/2023	10:50:01	21,54	°C	CH1	21,54	°C	ATC
2	18/05/2023	10:50:01	21,51	°C	CH2	21,51	°C	ATC
2	18/05/2023	10:50:01	21,15	°C	CH3	21,15	°C	ATC
2	18/05/2023	10:50:01	20,98	°C	CH4	20,98	°C	ATC

DATA SHEET

WARRANTY
3
YEARS



Measuring range	-200,00 ... +999,00 °C
Resolution	0,01 °C / 0,1 °C / 1 °C
Accuracy	± 0,1 °C (-200,0 ... -100,0 °C) ± 0,03 °C (-99,99 ... +99,99 °C) ± 0,1 °C (+100,0 ... +999,9 °C)
Data logger	Manual, automatic, programmed
Memory	190.000 record, internal memory.
Stability indicator	Yes - 3 levels
Inputs	4 PT100
Display	4", full-color, high-definition display
Multilingual	ITA - ENG - ESP- FR- DE
Brightness and contrast	Auto and manual (built-in light sensor)
Power supply	Batteries AA 4x 1,5 V - Mains 110/220 V (built-in power supply)
Unit of measure	°C - °F
Extra features	Min - Max Hold Alarms (audible and visual signal) Reference probe ID Password for cal and data protection
Auto off	After 20 minutes, can be disabled
Calibration	Single channel or multichannel whit data recall
Dimensions	184 x 85 x 45 mm
Weight	0,4 Kg
Warranty	3 years
Part number	50111212



Temp74_Eng_05/23_v1.0_DV

Distributed by

